



CODES	DESCRIPTION
Flashing Slow	Normal no call for heat
Flashing Fast	Normal call for heat
Continuous On	Replace Control
Continuous Off	Check Power
2 Flashes	External Lockout (Retried or recycles exceeded)
3 Flashes	Pressure Switch error
4 Flashes	Open high limit device
5 Flashes	Flame sensed when NO flame should be present
6 Flashes	115 VAC power reversed polarity or poor grounding
7 Flashes	Gas Valve circuit error
8 Flashes	Low Flame sens signal
9 Flashes	Check Igniter